

1 Comp. Loc. Radio

Select a system or component below to navigate to a location view:

- ◆ ⇒ ["1.1 Radio Systems Component Locations", page 1](#)
- ◆ ⇒ ["1.2 Satellite Radio Systems Component Locations", page 5](#)
- ◆ ⇒ ["1.3 RNS Low Navigation System Component Locations", page 9](#)
- ◆ ⇒ ["1.4 Navigation System II-D Component Locations", page 12](#)
- ◆ ⇒ ["1.5 RNS-E Navigation System Component Locations", page 15](#)
- ◆ ⇒ ["1.6 Telephone System Component Locations", page 19](#)
- ◆ ⇒ ["1.7 Telematics System Component Overview", page 21](#)

1.1 Radio Systems Component Locations

1.1.1 Radio Systems Component Locations - Sedan



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1 - CD Changer -R41-

- ☐ With iPod Baseplate -R192-
- ☐ Located in the glove compartment
- ☐ Component location same for all systems

2 - Inside Speaker -R70-

- ☐ Located center front of the instrument panel

3 - Radio -R-

- ☐ Located top of the center console
- ☐ Component location same for all systems

4 - Inside Microphone -R74-

- ☐ Located in the Front Interior Light -W1-
- ☐ Component location same for all systems

5 - Antenna Amplifier -R24- / Antenna Selection Control Module -J515-


- ☐ Located behind the roof end trim

6 - Amplifier -R12-

- ☐ Located behind the luggage compartment right side trim
- ☐ Component location same for all systems

7 - Bass Speaker -R100-

- ☐ Located in the parcel shelf
- ☐ Component location same for all systems - Sedan only





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Radio Systems Component Locations - Sedan continued

8 - Left Rear Bass Speaker -R15- and Right Rear Bass Speaker -R17-

- ☐ Located at the bottom of rear doors
- ☐ Component location same for all systems

9 - Left Rear Midrange Speaker -R34- and Right Rear Midrange Speaker -R35-


- ☐ At the top of rear doors
- ☐ Component location same for all systems

10 - Left Front Bass Speaker -R21- and Right Front Bass Speaker -R23-

- ☐ Located at the bottom of front doors
- ☐ Component location same for all systems


11 - Left Front Midrange Speaker -R26- and Right Front Midrange Speaker -R27-

- ☐ Located at the top of front doors
- ☐ Component location same for all systems



1.1.2 Radio Systems Component Locations - Avant

- 1 - CD Changer -R41-
 - ❑ With iPod Baseplate -R192-
 - ❑ Located in the glove compartment
- 2 - Inside Speaker -R70-
 - ❑ Located center front of the instrument panel
- 3 - Radio -R-
 - ❑ Located top of the center console
- 4 - Inside Microphone -R74-
 - ❑ Located in the Front Interior Light -W1-
- 5 - Amplifier -R12-
 - ❑ Located behind the luggage compartment right side trim
- 6 - Right rear window antennas
 - ❑ FM3
- 7 - Bass Speaker -R100-
 - ❑ Located behind the luggage compartment right side trim
 - ❑ Component location same for all systems - Avant only
- 8 - Rear window antennas
 - ❑ FM2
- 9 - Left Antenna Module -R108-
 - ❑ Located behind the luggage compartment left side trim
 - ❑ Component location same for all systems



Radio Systems Component Locations - Avant continued

10 - Left rear window antennas

- ❑ AM/FM1

11 - Left Rear Bass Speaker -R15- and Right Rear Bass Speaker -R17-

- ❑ Located at the bottom of rear doors

12 - Left Rear Midrange Speaker -R34- and Right Rear Midrange Speaker -R35-


- ❑ At the top of rear doors

13 - Left Front Bass Speaker -R21- and Right Front Bass Speaker -R23-

- ❑ Located at the bottom of front doors

14 - Left Front Midrange Speaker -R26- and Right Front Midrange Speaker -R27-

- ❑ Located at the top of front doors



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.2 Satellite Radio Systems Component Locations

1.2.1 Satellite Radio Systems Component Locations - Sedan

1 - CD Changer -R41-

- ☐ With iPod Baseplate -R192-
- ☐ Located in the glove compartment

2 - Inside Speaker -R70-

- ☐ Located center front of the instrument panel

3 - Inside Microphone -R74-

- ☐ Located in the Front Interior Light -W1-

4 - Radio, Telephone, Navigation System Antenna -R52-

- ☐ Ter/Sat/GPS/GSM
- ☐ Roof antenna
- ☐ Component location same for all systems

5 - Amplifier -R12-

- ☐ Located behind the luggage compartment right side trim

6 - Bass Speaker -R100-

- ☐ Located in the parcel shelf

7 - Antenna Selection Control Module -J515-


- ☐ Located behind the roof end trim
- ☐ Component location same for all systems

8 - Satellite Radio -R146-

- ☐ Located behind the luggage compartment left side trim
- ☐ Component location same for all systems

9 - Left Rear Bass Speaker -R15- and Right Rear Bass Speaker -R17-

- ☐ Located at the bottom of rear doors



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Satellite Radio Systems Component Locations - Sedan continued

10 - Left Rear Midrange Speaker -R34- and Right Rear Midrange Speaker -R35-

- ❑ At the top of rear doors

11 - Left Front Bass Speaker -R21- and Right Front Bass Speaker -R23-

- ❑ Located at the bottom of front doors


12 - Left Front Midrange Speaker -R26- and Right Front Midrange Speaker -R27-

- ❑ Located at the top of front doors

13 - Radio -R-

- ❑ Located top of the center console

Protected by copyright. Copying for private or commercial use is not permitted unless authorised by AUDI AG. AUDI AG assumes no liability with respect to the correctness of information in this document.



1.2.2 Satellite Radio Systems Component Locations - Avant

1 - CD Changer -R41-

- ☐ With iPod Baseplate -R192-
- ☐ Located in the glove compartment

2 - Inside Speaker -R70-

- ☐ Located center front of the instrument panel

3 - Radio -R-

- ☐ Located top of the center console

4 - Inside Microphone -R74-

- ☐ Located in the Front Interior Light -W1-

5 - Amplifier -R12-

- ☐ Located behind the luggage compartment right side trim

6 - Right rear window antennas

- ☐ FM3

7 - Bass Speaker -R100-

- ☐ Located behind the luggage compartment right side trim

8 - Radio, Telephone, Navigation System Antenna -R52-


- ☐ Ter/Sat/GPS/GSM
- ☐ Roof antenna

9 - Rear window antennas

- ☐ FM2

10 - Satellite Radio -R146-

- ☐ Located behind the luggage compartment left side trim



Unauthorized copying or reuse of any part of this page is prohibited. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Satellite Radio Systems Component Locations - Avant continued

11 - Left Antenna Module -R108-

- ❑ Located behind the luggage compartment left side trim

12 - Left rear window antennas

- ❑ AM/FM1

13 - Left Rear Bass Speaker -R15- and Right Rear Bass Speaker -R17-

- ❑ Located at the bottom of rear doors

14 - Left Rear Midrange Speaker -R34- and Right Rear Midrange Speaker -R35-


- ❑ At the top of rear doors

15 - Left Front Bass Speaker -R21- and Right Front Bass Speaker -R23-

- ❑ Located at the bottom of front doors

16 - Left Front Midrange Speaker -R26- and Right Front Midrange Speaker -R27-

- ❑ Located at the top of front doors



1.3 RNS Low Navigation System Component Locations

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.3.1 RNS Low Navigation System Component Locations - Sedan

1 - CD Changer -R41-

- ☐ With iPod Baseplate -R192-
- ☐ Located in the glove compartment

2 - Inside Speaker -R70-

- ☐ Located center front of the instrument panel

3 - Inside Microphone -R74-

- ☐ Located in the Front Interior Light -W1-

4 - Navigation System Antenna -R50-

- ☐ Located behind the roof end trim

5 - Antenna Selection Control Module -J515-

- ☐ Located behind the roof end trim

6 - Amplifier -R12-

- ☐ Located behind the luggage compartment right side trim

7 - Bass Speaker -R100-

- ☐ Located in the parcel shelf

8 - Left Rear Bass Speaker -R15- and Right Rear Bass Speaker -R17-

- ☐ Located at the bottom of rear doors

9 - Left Rear Midrange Speaker -R34- and Right Rear Midrange Speaker -R35-

- ☐ At the top of rear doors

10 - Left Front Bass Speaker -R21- and Right Front Bass Speaker -R23-


- ☐ Located at the bottom of front doors

11 - Left Front Midrange Speaker -R26- and Right Front Midrange Speaker -R27-

- ☐ Located at the top of front doors

12 - Radio/Navigation Display Unit Control Module -J503-

- ☐ Located at the top of the center console
- ☐ Component location same for all systems




A91-10436

Copyright. Copying for private or commercial purposes, in part or in full, is prohibited without the written permission of Audi AG. Audi AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by Audi AG.

1.3.2 RNS Low Navigation System Component Locations - Avant

- 1 - CD Changer -R41-
 - ☐ With iPod Baseplate -R192-
 - ☐ Located in the glove compartment
- 2 - Inside Speaker -R70-
 - ☐ Located center front of the instrument panel
- 3 - Inside Microphone -R74-
 - ☐ Located in the Front Interior Light -W1-
- 4 - Amplifier -R12-
 - ☐ Located behind the luggage compartment right side trim
- 5 - Right rear window antennas
 - ☐ FM3
- 6 - Bass Speaker -R100-
 - ☐ Located behind the luggage compartment right side trim
- 7 - Antenna -R11-
 - ☐ GPS/GSM
 - ☐ Roof antenna
- 8 - Rear window antennas
 - ☐ FM2
- 9 - Left Antenna Module -R108-
 - ☐ Located behind the luggage compartment left side trim

protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



A91-10437

RNS Low Navigation System Component Locations - Avant continued

10 - Left rear window antennas

- ❑ AM/FM1

11 - Left Rear Bass Speaker -R15- and Right Rear Bass Speaker -R17-

- ❑ Located at the bottom of rear doors

12 - Left Rear Midrange Speaker -R34- and Right Rear Midrange Speaker -R35-

- ❑ At the top of rear doors

13 - Left Front Bass Speaker -R21- and Right Front Bass Speaker -R23-


- ❑ Located at the bottom of front doors

14 - Left Front Midrange Speaker -R26- and Right Front Midrange Speaker -R27-

- ❑ Located at the top of front doors

15 - Radio/Navigation Display Unit Control Module -J503-

- ❑ Located at the top of the center console




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.4 Navigation System II-D Component Locations

1.4.1 Navigation System II-D Component Locations - Sedan

- 1 - CD Changer -R41-
 - ❑ Located in the glove compartment
- 2 - Inside Speaker -R70-
 - ❑ Located in the center front instrument panel
- 3 - Operating Electronics, Navigation Control Module -J402-
 - ❑ Located in top center console
 - ❑ Navigation System II-D Component Locations - Avant - location ⇒ [page 14](#)
- 4 - Navigation System Antenna -R50-
 - ❑ Located behind the roof end trim
- 5 - Amplifier -R12-
 - ❑ Located behind the luggage compartment right side trim
- 6 - Bass Speaker -R100-
 - ❑ Located in the parcel shelf
- 7 - Antenna Selection Control Module -J515-
 - ❑ Located behind the roof end trim
- 8 - Navigation Interface -R94-
 - ❑ Located behind the luggage compartment left side trim
- 9 - Navigation/TV Tuner -J415-
 - ❑ Located behind the luggage compartment left side trim



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.4.2 Navigation System II-D Component Locations - Avant

1 - CD Changer -R41-

- ❑ Located in the glove compartment

2 - Inside Speaker -R70-

- ❑ Located in the center front instrument panel

3 - Operating Electronics, Navigation Control Module -J402-

- ❑ Located in top center console

4 - Amplifier -R12-

- ❑ Located behind the luggage compartment right side trim

5 - Right rear window antennas

- ❑ FM3/TV3/TV4

6 - Right Antenna Module -R109-

- ❑ Located behind the luggage compartment right side trim

7 - Bass Speaker -R100-

- ❑ Located behind the luggage compartment right side trim


8 - Navigation System Antenna -R50-

9 - Rear window antennas

- ❑ FM2/TV2

10 - Left rear window antennas

- ❑ AM/FM1/TV1



permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Navigation System II-D Component Locations - Avant continued

11 - Left Antenna Module -R108-

- ❑ Located behind the luggage compartment left side trim


12 - Navigation Interface -R94-

- ❑ Located behind the luggage compartment left side trim

13 - Navigation/TV Tuner -J415-

- ❑ Located behind the luggage compartment left side trim

Protected by copyright
permitted unless
with respect




1.4.3

1.5 RNS-E Navigation System Component Locations

1.5.1 RNS-E Navigation System Component Locations - Sedan

- 1 - CD Changer -R41-
 - ☐ With iPod Baseplate -R192-
 - ☐ Located in the glove compartment
- 2 - Inside Speaker -R70-
 - ☐ Located center front of the instrument panel
- 3 - Inside Microphone -R74-
 - ☐ With Telephone Microphone -R38-
 - ☐ Located in the Front Interior Light -W1-
- 4 - Radio, Telephone, Navigation System Antenna -R52-
 - ☐ Ter/Sat/GPS/GSM
 - ☐ Roof antenna
- 5 - Antenna Selection Control Module -J515-
 - ☐ Located behind the roof end trim
- 6 - Amplifier -R12-
 - ☐ Located behind the luggage compartment right side trim
- 7 - Bass Speaker -R100-
 - ☐ Located in the parcel shelf
- 8 - Satellite Radio -R146-
 - ☐ Located behind the luggage compartment left side trim
- 9 - Left Rear Bass Speaker -R15- and Right Rear Bass Speaker -R17-
 - ☐ Located at the bottom of rear doors



Protects
permitt
with

RNS-E Navigation System Component Locations - Sedan

10 - Left Rear Midrange Speaker -R34- and Right Rear Midrange Speaker -R35-

- ❑ At the top of rear doors

11 - Left Front Bass Speaker -R21- and Right Front Bass Speaker -R23-

- ❑ Located at the bottom of front doors

12 - Left Front Midrange Speaker -R26- and Right Front Midrange Speaker -R27-


- ❑ Located at the top of front doors

13 - Navigation System with CD Drive Control Module -J401-

- ❑ Located at the top of the center console
- ❑ Component location same for all systems



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



A91-10360

1.5.2 RNS-E Navigation System Component Locations - Avant

1 - CD Changer -R41-

- ☐ With iPod Baseplate -R192-
- ☐ Located in the glove compartment

2 - Inside Speaker -R70-

- ☐ Located center front of the instrument panel

3 - Navigation System with CD Drive Control Module -J401-

- ☐ Located at the top of the center console
- ☐ Component location same for all systems

4 - Inside Microphone -R74-

- ☐ With Telephone Microphone -R38-
- ☐ Located in the Front Interior Light -W1-

5 - Amplifier -R12-

- ☐ Located behind the luggage compartment right side trim

6 - Right rear window antennas

- ☐ FM3

7 - Bass Speaker -R100-


- ☐ Located behind the luggage compartment right side trim

8 - Radio, Telephone, Navigation System Antenna -R52-

- ☐ Ter/Sat/GPS/GSM
- ☐ Roof antenna

9 - Rear window antennas

- ☐ FM2



RNS-E Navigation System Component Locations - Avant continued

10 - Satellite Radio -R146-

- ❑ Located behind the luggage compartment left side trim

11 - Left Antenna Module -R108-

- ❑ Located behind the luggage compartment left side trim

12 - Left rear window antennas

- ❑ AM/FM1

13 - Left Rear Bass Speaker -R15- and Right Rear Bass Speaker -R17-

- ❑ Located at the bottom of rear doors

14 - Left Rear Midrange Speaker -R34- and Right Rear Midrange Speaker -R35-


- ❑ At the top of rear doors

15 - Left Front Bass Speaker -R21- and Right Front Bass Speaker -R23-

- ❑ Located at the bottom of front doors

16 - Left Front Midrange Speaker -R26- and Right Front Midrange Speaker -R27-

- ❑ Located at the top of front doors



1.6 Telephone System Component Locations

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

1.6.1 Telephone System Component Locations - Sedan

1 - Inside Speaker -R70-

- ☐ Vehicles without radio
- ☐ Located center front of the instrument panel

2 - Telephone Baseplate -R126-

- ☐ Located on top of the instrument panel

3 - Telephone Microphone -R38-

- ☐ Located in the Front Interior Light -W1-

4 - Radio, Telephone, Navigation System Antenna -R52-


- ☐ Ter/Sat/GPS/GSM
- ☐ Roof antenna

5 - Not installed

6 - Telephone Transceiver -R36-

- ☐ Located in the electronics box under the right front seat


Protected by copyright. Copying for private use is permitted unless authorised by AUDI AG. The copyright holder assumes no responsibility with respect to the correctness of information.



1.6.2 Telephone System Component Locations - Avant

- 1 - Inside Speaker -R70-
 - ☐ Vehicles without radio
 - ☐ Located center front of the instrument panel
- 2 - Telephone Baseplate -R126-
 - ☐ Located on top of the instrument panel
- 3 - Telephone Microphone -R38-
 - ☐ Located in the Front Interior Light -W1-
- 4 - Not installed
- 5 - Radio, Telephone, Navigation System Antenna -R52-
 - ☐ Ter/Sat/GPS/GSM
 - ☐ Roof antenna
- 6 - Telephone Transceiver -R36-
 - ☐ Located in the electronics box under the right front seat

Protected by copyright. Copying for private use is permitted unless authorised by Audi AG. The copyright holder assumes no responsibility with respect to the correctness of the information.



1.7 Telematics System Component Overview

1.7.1 Telematics System Component Overview - Sedan

1 - Radio -R-

- ☐ Located center of the instrument panel

2 - Instrument Cluster Control Module -J285-

3 - Telephone/Telematics Control Module -J526-

- ☐ Located in Electronics box under the front passenger seat
- ☐ Telematics System Component Overview - Avant - location ⇒ [page 23](#)

4 - Harness connector for cellular telephone preparation

- ☐ Located in the center console storage compartment

5 - Telematics Control Head -E264-

- ☐ With telematics system control buttons
- ☐ Integrated with front interior lamp module and inside microphone

6 - Navigation System Antenna -R50- and Auxiliary Antenna (Telematics) -R90-

7 - Telephone Antenna -R65-


- ☐ Located under the rear headliner trim

8 - Multi-function steering wheel

9 - Radio system speaker

10 - Radio system speaker

11 - Auxiliary Speaker (Telematics) -R91-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept responsibility with respect to the correctness of information in this document. Copyright by AUDI AG.

A91-0642

1.7.2 Telematics System Component Overview - Avant

1 - Radio -R-

- ❑ Located center of the instrument panel

2 - Telephone Antenna -R65-

- ❑ Located under front bumper cover

3 - Antenna Splitter -R87-

- ❑ Located in Electronics box under the front passenger seat

4 - Instrument Cluster Control Module -J285-

5 - Telephone/Telematics Control Module -J526-

- ❑ Located in Electronics box under the front passenger seat

6 - Harness connector for cellular telephone preparation

- ❑ Located in the center console storage compartment

7 - Telematics Control Head -E264-

- ❑ With telematics system control buttons
- ❑ Integrated with front interior lamp module and inside microphone

8 - Telephone Antenna 2 -R127-

- ❑ Located under the rear bumper cover

9 - Navigation System Antenna -R50- and Auxiliary Antenna (Telematics) -R90-


10 - Multi-function steering wheel

11 - Radio system speaker

12 - Radio system speaker

13 - Auxiliary Speaker (Telematics) -R91-

- ❑ Located in the driver storage compartment



Protected by copyright. Copying for private or commercial use is not permitted unless authorised by AUDI AG. AUDI AG is not responsible with respect to the correctness of information.

A91-0643